

1. Place the bracket tight against the end of the floor track so that the tab is centered in the channel of the extrusion.
2. Use the two holes as guides and drill $\frac{1}{4}$ " diameter x $\frac{3}{4}$ " deep holes with a $\frac{1}{4}$ " cement drill bit.
3. Remove any cement dust from the holes and insert the two concrete anchors. Make sure the top surface of the anchors are flush with the floor surface.
4. Place the black bumper into the channel of the extrusion so that the edge is even with the end of the track.
5. Place the bracket into position so that the tab captures the black bumper as shown in the illustration and secure with the two screws supplied. Make sure the screws are tight and the bracket is tight against the floor, the tab of the bracket should be pinching the black bumper, which holds it in place.

