

**Thank you for your purchase of Wenger Storage Products!
Please follow these steps to help ensure a safe and successful delivery.**

Before Unloading

Confirm the delivery location:

Make sure that your facility can receive this shipment.



*Individual cabinets may weigh
several hundred pounds.*

Lift Gate Delivery (see page 2)

Prior to unloading, inspect the load for freight damage before accepting the product.

Line up your crew (four people recommended):

1. Liftgate delivery means the carrier driver will lower the products to the curb via a liftgate truck.
2. The delivery will require assistance from usually four people at your facility to help the driver.
3. Safely offload the products from the liftgate at curbside height.
4. Your crew is responsible for transporting the products from curbside into the building and for completing the final assembly/installation.

Box Truck Delivery (see page 3)

Prior to unloading, inspect the load for freight damage before accepting the product.

Line up your crew (four people recommended):

1. Box truck delivery means the products must be unloaded from the truck by people at your facility.
2. Your crew is responsible for transporting the products from the truck into the building and for completing the final assembly/installation.

Lift Gate Delivery

Unloading Assembled Cabinets:

***Inspect the load for freight damage before accepting the product.**

1. Slide the cabinet onto the liftgate and lower it to the ground.
2. Tip the back of the cabinet onto a cart. Four people are recommended.

Do not tip the cabinet onto the front or side, damage could occur.

3. Move the cabinet into the facility.



Unloading Ready-To-Assemble Cabinets:

***Inspect the load for freight damage before accepting the product.**

1. Cut the bands:
The cartons will arrive securely banded to a pallet. Simply cut the bands and remove the shrink wrap to offload the cartons.

Note: Loose parts may be packed in between the cartons.

2. Unload:
 - a. Slide the cartons onto the liftgate and lower them to the ground.
 - b. Transfer the cartons onto a cart. Four people are recommended.
 - c. Move the cartons into the facility.



Box Truck Delivery

Unloading Assembled Cabinets:

***Inspect the load for freight damage before accepting the product.**

1. Slide the cabinet to the edge of the truck and lower it to the ground.
Do not drop the cabinet to the ground, damage could occur.
2. Tip the back of the cabinet onto a cart. Four people are recommended.
Do not tip the cabinet onto the front or side, damage could occur.
3. Move the cabinet into the facility.



Unloading Ready-To-Assemble Cabinets:

***Inspect the load for freight damage before accepting the product.**

1. Cut the bands:
The cartons will arrive securely banded to a pallet. Simply cut the bands and remove the shrink wrap to offload the cartons.
Note: Loose parts may be packed in between the cartons.
2. Unload:
 - a. Slide the cartons to the edge of the truck.
 - b. Transfer the cartons onto a cart. Four people are recommended.
 - c. Move the cartons into the facility.

