

STAGE BOXES



Enhance the excitement.

Wenger Stage Boxes will surprise you – in fact, they might just change the way you look at choreography and props for your Show Choir. They're made of tough polyethylene molded material that won't break or splinter yet they're lightweight, with built-in handles for gripping. Wenger Stage Boxes are extremely stable and available in multiple sizes that lock together with a revolutionary patented connector that you simply push and turn. No bolts or screws – and no tools. This makes it easy to adapt to the ever-changing movement and choreography developed for each show ...even quick set changes within each performance!



Large Stage Box
24" x 24" w x 18" h



Medium Stage Box
18" x 12" w x 16" h



Small Stage Box
16" x 12" w x 8" h

Wenger®

Your Performance Partner

STAGE BOXES

When combined with Wenger flipFORMS® or Versalite® platforms, Wenger Stage Boxes become a great way to expand your options for abstract settings. Like flipFORMS and Versalite, the black color won't steal the spotlight during your show. Color is black throughout so surface scratches will not be visible or become unsightly over time. And when the show is over, Wenger Stage Boxes stack compactly together and store in a small space.



Designed to partner with Versalite staging and flipFORM platforms.



Stage Boxes from Wenger – enhancing the excitement of every Show Choir performance.

PRODUCT SPECIFICATIONS:

- Saves time by eliminating construction.
- Lighter in weight than wood and safer to stack.
- Molded polyethylene construction provides durability and longevity.
- Black color is through the entire surface so scratches are not visible.
- Shell has skid resistant texture molded into surface for added safety and sure-footedness.
- Rubber feet prevent box from moving/slipping on smooth surfaces.
- Boxes are sized to mimic basic furniture items and correlate with Wenger Versalite staging and flipFORM platforms.
- Boxes can be combined and connected to create any type of rehearsal furniture.
- No tools are required to connect boxes.
- Patented connection design allows for quick and secure side-to-side, side-to-top, or top-to-top connection.
- Hollow underside for carrying props and other items.
- Molded thru-handles for easy transportation by one person.

- Protruding feet nest in recessed pockets to allow boxes to stack securely. One set of three stores in a 24" x 24" x 18" space (61cm x 61cm x 45cm).
- 5-year warranty.
- Patented.

029A105 Large Stage Box, 24"l x 24" w x 18" h (61cm x 61cm x 45cm), 32 lb (14.5 kg)

029A104 Medium Stage Box, 18"l x 12" w x 16" h (45cm x 41cm x 31cm), 16 lb (7.25 kg)

029A104 Small Stage Box, 16"l x 12" w x 8" h (31cm x 41cm x 21cm), 8 lb (3.63 kg)

© 2010 Wenger Corporation
USA/1-10/2M/W/LT0139B

WENGER CORPORATION

555 Park Drive, PO Box 448
Owatonna, MN 55060-0448
Phone 800.4WENGER (493-6437)
Fax 507.455.4258
Parts & Service 800.887.7145

WENGER CORPORATION

CANADA OFFICE
Phone 800.268.0148

WENGER CORPORATION

BEIJING REPRESENTATIVE OFFICE
Tel 0086-10-84972502
Fax 0086-10-84972575

WORLDWIDE

Phone 1.507.455.4100
Fax 1.507.774.8576

WEB SITE

wengercorp.com

Wenger®

Your Performance Partner