



## Unpacking Instructions Media Storage Systems Fixed Media Cabinets



The Adjustable Shelves are held in place during shipping with two screws.

These screws must be removed and discarded before the shelves can be removed.



Tilt each Adjustable Shelf up on one side slightly as shown and pull it out to remove.