

# Assembly Instructions Suspended Cymbal Holder and Cymbal Cradle

for the Percussion Workstation


Basic Instructions only!
For more detailed product information, refer to the teacherTAXI Owner's Manual 204A099.

#### ACAUTION

Make sure anyone assembling, installing or using these products has read and understands these instructions.

## ACAUTION

Failure to comply with Warnings and Cautions in this document or on the equipment can result in damage to property or injury.



## **Contents**

Supplied Hardware - Suspended Cymbal Holder	. 2	Suspended Cymbal Holder Assembly	
Parts List - Suspended Cymbal Holder	. 2	Cymbal Cradle Assembly	
Supplied Hardware - Cymbal Cradle	. 2		
Parts List - Cymbal Cradle	. 2		



Visit the Percussion Workstation web page at wengercorp.com for more information.

Note: Please read and understand these instructions before proceeding.

Note: If you need additional information, contact Wenger Corporation using the information below.


©Wenger Corporation 2024 Printed in USA 2024-10 Part #147H182-02

# Supplied Hardware - Suspended Cymbal Holder



## Parts List - Suspended Cymbal Holder

Item	Description
1	Upper Bracket Assembly
2	Lower Plate
3	3/8" ID Washer
4	5/16-18 Wing Nut
5	Rod Assembly (includes fasteners)




# Supplied Hardware - Cymbal Cradle




# Parts List - Cymbal Cradle

Item	Description
1	Lower Plate
2	5/16-18 Wing Nut
3	Upper Bracket
4	Cymbal Cradle




# Suspended Cymbal Holder Assembly


- 1. Set the upper bracket on the percussion cabinet rail.
- 2. Loosely assemble the lower plate to the upper bracket, using a washer and a 5/16-18 wing nut.



4. Assemble the rod assembly to the post of the upper bracket assembly as shown by adjusting the wing nut.




- 5. Remove the upper wing nut and nylon spacer. Install the cymbal, and secure with the spacer and a wing nut.
- 6. Move the upper bracket along the rail until the cymbal is in a convenient position, then lock securely with a lower wing nut.



# **Cymbal Cradle Assembly**

1. Set the upper bracket on the percussion cabinet rail, with the flange pointing down as shown.



- 2. Insert the cradle into the hole in the upper bracket.
- 3. Secure the cradle loosely with the lower plate and a 5/16-8 wing nut.
- 4. Move the cradle along the rail to a convenient position, then lock securely with the wing nut.

