
UltraStor® Storage Cabinets

- Variety of styles tailored to different storage needs
- Wall panels are 3/4" (19 mm) thick industrial grade composite wood with no added formaldehyde and polyester laminate finish in Wenger standard colors


Wenger

CORPORATION

- · Patented shelves are blow-molded polyethylene mounted with self-lock shelf supports
- Grooved shelves allow air to circulate
- Edging is 1/8" (3 mm) radiused PVC
- Door options:
 - Individual compartment or full-length wood door same construction as wall panels
 - Individual compartment or full-length straight grille door 3/16" diameter welded steel grille construction with powder-coat paint finish
 - Individual compartment waterfall grille doors ONLY 1/4" diameter welded steel grille construction with powder-coat paint finish
 No door
- · Cabinets have four or five adjustable steel leveling glides for uneven floors
- Doors include heavy-duty 5-knuckle institutional ANSI/BHMA A156.9, Grade 1 hinge, through-bolted to cabinet wall
- Locking slide bolt with strike plate designed for padlocks with 3/4" (19 mm) maximum vertical shackle clearance
- Assembly required for all cabinets wider than 28" (711 mm)
- UL GREENGUARD certified product certified for low chemical emissions: ul.com/gg UL 2818
- Environmental attributes and LEED compliance for our products can be found at wengercorp.com/GREEN or by contacting
 your Wenger representative
- Ten-year warranty




Note: Doors must be included at the time of ordering as they can not be installed later.



Standard compartment sizes.

Cabinets are shown without doors and 38" height cabinets are shown without work surface tops.


*Narrow width sizes do not fit trombones. Wider tenor saxophone cases may not fit in #5, #7, #24, #28, #55 and #61 narrow compartment sizes.



Standard compartment sizes.

Cabinets are shown without doors and 38" height cabinets are shown without work surface tops.

*Narrow width sizes do not fit trombones. Wider tenor saxophone cases may not fit in #5, #7, #24, #28, #55 and #61 narrow compartment sizes.



Standard compartment sizes.

Cabinets are shown without doors and 38" height cabinets are shown without work surface tops.

*Narrow width sizes do not fit trombones. Wider tenor saxophone cases may not fit in #5, #7, #24, #28, #55 and #61 narrow compartment sizes.

Note: Doors must be included at the time of ordering as they can not be installed later.

Work surface tops must be specified at time of order for 38" high cabinets. Full doors are not available for cabinets 69-3/4" or shorter or 18-3/4" wide or narrower.



© 2024 Wenger Corporation USA/2024-04

 Minnesota Location
 Wenger Phone 800.4WENGER (493-6437) Wenger Worldwide +1.507.455.4100 | Parts & Service 800.887.7145 | wengercorp.com

 GearBoss Phone 800.493.6437 | gearboss.com
 555 Park Drive, PO Box 448 | Owatonna | MN 55060