

Assembly Instructions and Owner's Manual Inside

⚠ CAUTION

Failure to follow these instructions could result in serious injury or damage to the shell.

⚠ CAUTION

Read the Assembly Instructions before removing the pallet or unbanding the shell.

DO NOT REMOVE OR DISASSEMBLE THE PALLET AT THIS TIME.

If There Is A Forklift and Loading Dock

Remove the shell from the truck upright as it was shipped.


If There Is A Loading Dock, But No Forklift

Shells are top-heavy, Keep the shell upright. Slide it off the truck, leading with one of the narrow ends or move with a pallet jack.


If There Is No Loading Dock

The delivery truck is required to have a lift gate.

CAREFULLY lower the pallet to the ground. **DO NOT DROP!**



Single Unit
Packaged Assembly
weighs 710 lbs (322 kg)



Double Unit
Packaged Assembly
weighs 1220 lbs (553 kg)