


Owner's Manual GearBoss Garment Bar Accessory



Note: Please read and understand the GearBoss Garment Bar Accessory Owner's Manual before attempting installation, assembly, or use.

Note: Remove all items from the shipping containers and sort the components by type, size, etc. Refer to the illustrations on the following pages. If you need additional information about your GearBoss Garment Bar Accessory, contact the Wenger Corporation using the information listed below.

SAFETY

Throughout this manual you will find Cautions which are defined as follows.

Caution; failure to follow the instruction may result in injury or damage to property.

Read and understand the following instructions before using or installing any GearBoss Accessory.

WARRANTY

The GearBoss Garment Bar Accessory is guaranteed free of defects in materials and workmanship for five full years.

Our guarantee assures you of either a full refund or repair or replacement of the defective materials or workmanship without charge, at the discretion of our Customer Service Department. Just call a Customer Service Representative at 1-800-887-7145 and state the reason you are dissatisfied. If a product return is necessary, your representative will issue a return authorization. This is your sole remedy for breach of this warranty.


Should you have a question or problem with any Wenger product, don't hesitate to call, even if the product is past warranty. It's important to us that all our customers be satisfied.

This is the sole warranty made by Wenger. Wenger disclaims all other warranties, including the warranties of merchantability and fitness for a particular purpose, as well as all liability for incidental, consequential, special, and indirect damage. Wenger liability for direct damages shall be limited to the amount you paid for the product involved. Wenger reserves the right to make product changes without obligation to incorporate such changes into products previously sold.

Some states do not allow the exclusion or limitation of damages or warranties, so the above may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

©Wenger Corporation 2008 Printed in USA 02/08 Part #241A346-01

GARMENT BAR INSTALLATION



Attach the Garment Bar to the GearBoss Shelving

- 1. Install the tube holder bracket (item 2) onto the underside of the shelf arm (item 6) by inserting the tab into the front hole and secure the bracket by inserting a carriage bolt (item 3) through the back hole of the shelf arm and bracket as shown using a wing nut (item 4). Do not tighten the wing nut yet.
- 2. Place one end of the garment bar (item 1) through the bracket and position the other end of the bar so that step 1 can be repeated for the other end of the shelf.
- 3. Tighten the wing nuts on both ends of the garment bar.

PARTS LIST

<u>ltem</u>	<u>Qty</u>	<u>Description</u>
1	1	Garment Bar
2	2	Tube Holder Bracket
3	2	Carriage Bolt, 3/8 - 16 x 3/4
4	2	Wing Nut, 3/8 - 16
5	2	End Plug