

Vantis™ Wall Controller

The Vantis™ Wall Controller provides one of the most powerful, intuitive and easy to use control systems for stage equipment including hoists, travelers and acoustical banners. With powerful presets for up to 24 motorized machines, targets that are easily recordable and tailored permissions for security, this controller is a great fit for a multitude of different venues.

Applications

Venues with up to twenty-four motorized machines that need the need to quickly access stored positions, easily program new presets and tailor permissions based on user.

- K-8 School
- High Schools
- College/University
- Performing Arts Centers
- Worship

Key Features

- Up to twenty-four (24) machines
- Variable speed control
- Up to eight (8) user programmable targets per machine
- User programmable presets
- Wall cabinet and rack mount options
- Operation of various set types including hoists, acoustic banners and travelers
- Load sensing capabilities
- Groups for linking position of multiple machines
- Adjustable screen brightness to prevent light leaks on stage
- Current position shown at all times and target/end position shown whenever machine is selected on machines with position read-out
- Current load and max load shown on machines with load sensing

Dimensions

Wall Cabinet Mount – 24" x 24" x 9-1/2" (610 x 610 x 241 mm)

Rack Mount – 19" x 10-1/2" x 9-1/2" (483 x 267 x 241 mm)

Hardware

- 10" touchscreen
- GO, E-Stop, Speed Wheel, (2) USB, key switch
- Optional remote operator pendant

Safety

- Emergency Stop Operator
- Hold-to-Run operation
- Multi-Level security
- Status/Alarm indication



**VANTIS Wall Controller
Rack Mount Cabinet**

Operations

- Manual Move/Jog Mode
 - Move a single machine
 - Move multiple machines in the same or opposing directions
 - Load targets for one or more machine
 - Record targets for one or more machine
- Presets
 - Record presets with one or more machine
 - Use machines' targets when recording
 - Ability to record a snapshot using current positions
 - Rename presets
 - Selecting a preset clearly shows which machines will be moved and in which direction
- Machine Information
 - View machine status including name, position, load, target position and speed
 - Load sensing
 - Turn on/off
 - Guided load learning process to reduce the possibility of an unintended load fault
 - Travel adjustments to easily modify soft limits based when hanging objects on the set
- Settings
 - Adjust screen brightness
 - User set-up
 - Revert/Recovery – quickly recover previous work
 - View/export log file – traces every action on the console for diagnosing problems
 - Locked groups
 - Assign multiple machines to a group so they will always travel together

Electrical Information

Input 120VAC

Warranty and Support

Three-Year Warranty against defects in materials or workmanship is provided on all J.R. Clancy equipment. Our warranty is contingent on operation by trained personnel and an annual equipment inspection by a Wenger Corporation-authorized technician.

24/7 factory technical service and support.

Inspection and maintenance are available through our J.R. Clancy T.I.M.® (Train, Inspect, Maintain) Program. For more information call 800-836-1885 or email service@wengercorp.com.

Additional Information

Additional information on J.R. Clancy systems is available at jrclancy.com or performance.wengercorp.com.

Order Information

060-VANTIS-WALL
060-VANTIS-RACK



MUSIC EDUCATION AND PERFORMING ARTS

Owatonna Office: Phone 800.4WENGER (493-6437) Worldwide +1.507.455.4100 | Parts & Service 800.887.7145 | wengercorp.com
555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448

Syracuse Office: Phone 800.836.1885 Worldwide +1.315.451.3440 | jrclancy.com | 7041 Interstate Island Road | Syracuse | NY 13209-9713

ATHLETICS Phone 800.493.6437 | email gearboss@wengercorp.com | gearboss.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448