
UNIVERSAL TABLET STAND





Tablet stands that are adjustable and stable.

Take the traditional music stand into the digital age with Wenger's Universal Tablet Stand. No matter what tablet you use, with a case or without. Wenger has an option for you. Wenger's sturdy, stable base and support keep your investment safe. Adjust height, angle and orientation to put your digital music right where you can see it. Built on the same trusted base as our Bravo® Music Stand.



UNIVERSAL TABLET STAND

UNIVERSAL TABLET STAND

Use almost any smartphone or tablet as your music stand, with or without a case from 5" to 13.3" (13-34 cm).

- Up to 11/4" (3 cm) thick
- Secure holding
- · Brass spring friction height adjustment mechanism adjusts height from 29" to $50^{1/4}$ " (74 to 128 cm) (floor to center of support).
- Spring-loaded finger clamps with rubber coating
- Adjustable arms with side screw
- Adjustment 360° rotation with locking positions in portrait and landscape orientations
- Self-tightening hinge for easy angle adjustment
- 1- year warranty on mount;
 - 5- year on base/post

040A149 Universal Tablet Stand, 5.1 lbs (2 kg)

















WENGER CORPORATION Phone 800.4WENGER (493-6437) Worldwide 1.507.455.4100 | Fax 507.455.4258 Worldwide 1.507.774.8576

Parts & Service 800.887.7145 | Canada Office 800.268.0148 | Web wengercorp.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448

GEARBOSS

Phone 800.493.6437 | email gearboss@wengercorp.com | Web gearboss.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448