



Your Performance Partner

Assembly Instructions Large Storage Cart for Music Stands

BEFORE YOU BEGIN


NOTE: The Storage Cart can be used with Wenger's Classic, Bravo, Preface, Roughneck, and most other music stands, but not with the Wenger Director Stand or Gig Stand.

Remove all items from the shipping Carton, and lay them out approximately in their final position. Refer to the assembled view below, and the exploded drawings on the following pages.


Remove all items from the hardware bag, and determine where all fasteners will be used.

TOOLS REQUIRED


- Two 1/2" open-end or socket wrenches; one 3/4" wrench



- Hammer



- Phillips screwdriver




FASTENERS USED FOR ASSEMBLY


- ④ Pushnut




- ⑪ Machine Screw



- ⑦ Capscrew



- ⑬ Capscrew




- ⑧ Lock Nut, Thin, 5/16"



- ⑮ Nut, 1/2"




- ⑳ Washer, 1/2"



- ⑱ Lock Washer, 1/2"



To load music stands onto cart, first fold the desk up as shown.



Item	Qty.	Description
1	1	Axle assembly
3	2	Wheel, 8" dia.,
4	2	Pushnut, 1/2"
5	1	Base assembly
6	4	Tube, support
7	6	Capscrew, 5/16-18 x 3-1/2"
8	12	Nut, lock, full, 5/16-18
9	4	Tube, handle
10	4	Grip, handle
11	4	Screw, machine, Phillips flat-head, 5/16-18 x 1-1/2"
12	4	Tubing, clear

Item	Qty.	Description
13	2	Capscrew, 5/16-18 x 2-1/4"
14	2	Caster, swivel, 5" dia.
15	2	Nut, 1/2-13
17	8	Cap, insert, 7/8" O.D.
18	2	Washer, lock, 1/2"
19	2	Bushing .50 dia. x 2.313 long
20	2	Washer, 1/2 I.D. x 1 1/2 O.D.

ASSEMBLY — LARGE CART

