




# Assembly Instructions Book & Music Storage Rack for Wenger Nota™ Chairs



## CONTENTS

Warranty .....	2
Assembly .....	3

**Note:** Please read and understand the Book & Music Storage Rack Assembly Instructions before attempting installation, assembly, or use.

**Note:** Remove all items from the shipping containers. Refer to the illustrations on the following pages. If you need additional information, contact the Wenger Corporation using the information listed below.

# **WARRANTY**

---

The Wenger Book & Music Storage Rack is guaranteed free of defects in materials and workmanship for five full years.

Our guarantee assures you of either a full refund or repair or replacement of the defective materials or workmanship without charge, at the discretion of our Customer Service Department. Just call a Customer Service Representative at 1-800-887-7145 and state the reason you are dissatisfied. If a product return is necessary, your representative will issue a return authorization. This is your sole remedy for breach of this warranty.

Should you have a question or problem with any Wenger product, don't hesitate to call, even if the product is past warranty. It's important to us that all our customers be satisfied.

This is the sole warranty made by Wenger. Wenger disclaims all other warranties, including the warranties of merchantability and fitness for a particular purpose, as well as all liability for incidental, consequential, special, and indirect damage. Wenger liability for direct damages shall be limited to the amount you paid for the product involved. Wenger reserves the right to make product changes without obligation to incorporate such changes into products previously sold.


Some states do not allow the exclusion or limitation of damages or warranties, so the above may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

# ASSEMBLY

---

1. Place the Nota Chair upside down on a table or bench covered with a pad or blanket to protect the seat surface.
2. Rotate the Book & Music Storage Rack to insert the two Front Posts all of the way into both of the holes in the inside of the Front Legs.

**Note:** Be sure that the two Front Posts are inserted all of the way into the holes and remain inserted for the remaining steps.



## ASSEMBLY (CONTINUED)

3. Rotate the Storage Rack toward the chair and snap the Rear Loops between the Seat and the Back Leg Cross Tube as shown.  
The Storage Rack must be squeezed together by pushing the back end of the Storage Rack towards the Front Legs to allow the Rear Posts to snap over the Back Leg Cross Tube.

Insert one of the Rear Loops into place first then the other.

This decreases the amount of force required to engage the Rear Loops.

### CAUTION

*To avoid the possibility of pinching hands or fingers, grip the Storage Rack with both hands at a point far enough away from the Rear Loops when snapping them over the Back Leg Cross Tube.*

