




Installation Instructions Peg Board Accessory for the GearBoss® Shelving System

Basic Instructions only!
For more detailed product information, refer to the
GearBoss Shelving System Installation Instructions 241A298.

⚠ CAUTION
Make sure anyone assembling, installing or using this product has read and understands these instructions.

⚠ CAUTION
Failure to comply with Warnings and Cautions in this document or on the equipment can result in damage to property or serious injury.

⚠ CAUTION
Never hang more than 40 lb (18 kg) of total weight from the peg board.



Contents


Supplied Hardware	2	Installation	4
Parts List	3		




Visit the GearBoss Shelving System web page at gearboss.com for more information.

Note: Please read and understand these instructions before proceeding.
Note: If you need additional information, contact Wenger Corporation using the information below.


Supplied Hardware




Panel Plate




#10 x 5/8"
Pan Head Screw



3/8-16 x 2-3/4"
Cap Screw



3/8-16
Wing Nut




Plastic Extrusion

NOTICE

The 1/4" thick peg board material is not supplied by Wenger Corporation and must be purchased separately. See the Installation procedure for measurement requirements.

Parts List


Item	Description
1	Panel Plate
2	#10 x 5/8" Pan Head Screw
3	3/8-16 x 2-3/4" Cap Screw
4	3/8-16 Wing Nut
5	Plastic Extrusion
6	Peg Board (not included) <i>Must be purchased separately</i>



Installation


1. The plastic extrusions (5) may need to be cut to fit between any components that are mounted to the shelf upright tubes.

Measure and cut both plastic extrusions to fit onto the shelf upright tubes as necessary.




Installation (continued)

2. Attach one panel plate (1) to an end of each plastic extrusion using two #10 x 5/8" pan head screws (2).




3. With the panel plate side down, push the extrusion assemblies onto the shelf upright tubes.




Installation (continued)

4. Drill a 3/8" hole near the bottom of each extrusion assembly.
Horizontally center the hole over the crease in the extrusion and vertically align the hole with an existing hole in the shelf upright tube.
5. Attach the bottom of each extrusion to the upright using a 3/8-16 x 2-3/4" cap screw (3) and 3/8-16 wing nut (4).
6. Drill a 3/8" hole near the top of each extrusion assembly.
Horizontally center the hole over the crease in the extrusion and vertically align the hole with an existing hole in the shelf upright tube.
7. Attach the top of each extrusion to the upright using a 3/8-16 x 2-3/4" cap screw (3) and 3/8-16 wing nut (4).



Installation (continued)

8. Insert a peg board (6) to fit within the plastic extrusions.
 - a. Cut a 1/4" thick peg board (not supplied) to fit the width within the side notches in both plastic extrusions.
 - b. Cut the peg board to match the height of the plastic extrusions.
 - c. Fit the peg board into the side notches of both plastic extrusions and to sit onto the panel plates.



This page is intentionally blank.