

Contents

Important User Information	2	Adjustment.	5
Safety Precautions	2	Removing the Tuba from the Stand	7
Assembly	3	Replacement Parts	8



Visit the instrument stands and holders web page at wengercorp.com for more information.

Note: Please read and understand these instructions before proceeding.
Note: If you need additional information, contact Wenger Corporation using the information below.

Important User Information

General

Copyright © 2024 by Wenger Corporation

All rights reserved. No part of the contents of this manual may be reproduced, copied, or transmitted in any form or by any means including graphic, electronic, or mechanical methods or photocopying, recording, or information storage and retrieval systems without the written permission of the publisher, unless it is for the purchaser's personal use.

Printed and bound in the United States of America.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Wenger Corporation. Wenger Corporation does not assume any responsibility for any errors that may appear in these instructions.

In no event will Wenger Corporation be liable for technical or editorial omissions made herein, nor for direct, indirect, special, incidental, or consequential damages resulting from the use or defect of these instructions. The manufacturer reserves the right to change this product at any time.

The information in this document is not intended to cover all possible conditions and situations that might occur. The end user must exercise caution and common sense when assembling or installing Wenger Corporation products. If any questions or problems arise, call the Wenger Corporation at (800) 4WENGER (493-6437) or +1-507-455-4100 worldwide.

Manufacturer

The Tuba Tamer™ is manufactured by:

Wenger Corporation
555 Park Drive
Owatonna, MN 55060
(800) 4WENGER (493-6437) • +1 (507) 455-4100
wengercorp.com

Intended Use

- This product is intended for indoor use in normal ambient temperature and humidity conditions – it must not be exposed to prolonged outside weather conditions.
- This product is intended to be assembled and used only as described in these instructions.

Warranty

Warranty information is available at wengercorp.com.

Safety Precautions

Throughout this document you may find cautions and warnings which are defined as follows:

- **WARNING:** Failure to follow the instruction could result in serious injury or damage to property.
- **CAUTION:** Failure to follow the instruction could result in minor injury or damage to property.

Read all of these safety instructions before using the equipment.

⚠ CAUTION


Make sure anyone assembling, installing or using this product has read and understands these instructions.

⚠ CAUTION


Failure to comply with Warnings and Cautions in this document or on the equipment can result in damage to property or injury.

Assembly


1. Set the base on the floor.
2. Remove both set screws from the base using a 3/16" hex wrench (included).
3. Slide the cap onto the base, aligning the hole with the set screw holes.
4. Lower the upright post into the base with the tab at the bottom facing the same side as the set screw holes.
5. Reattach the set screws.



6. Loosely turn the handle into the upright post.




7. With the indentation facing the handle, lower the stem assembly into the upright post. Secure it in place by tightening the handle.




Assembly (continued)

8. Loosen the three knobs on the t-channel and insert the three arms, bent end first. Tighten the knobs.




9. Slide the three bracket assemblies onto the arms, knob-end first. Tighten the knobs.
10. Make adjustments to properly fit your instrument. See the procedures on the following pages.




Adjustment

1. Lower the bottom arm as far down as possible and tighten the knob.
2. Move the left arm as far out as possible and tighten the knob.
3. Move the bracket assemblies to their approximate locations but don't tighten knobs.



For Tubas with Valves Located on the Opposite Side from the Player



**For Tubas with Valves Located on the Same Side as the Player
(or with Valves in Perpendicular Position)**

Adjustment (continued)

- Remove the right arm from the t-channel.

CAUTION

Two people are required for steps 5 through 7.

- Set the tuba in the stand.


NOTICE

Be sure long vinyl-coated supports on the bracket assemblies are turned so they extend over small tubing on instrument. This is particularly important on models such as the king bell-up type, which have small tubing next to the main tubing. On these models, the bracket assemblies must also be moved out as far as possible.

- Reinsert right arm into the t-channel.
- Press the right arm and bracket assembly tightly against the tuba and tighten the right arm knob.
- Tighten all bracket knobs.


CAUTION

Be sure that the tuba is held tightly by the brackets. Any looseness may allow the tuba to be damaged.



Adjustment (continued)

9. To adjust the height, carefully loosen the height handle and move the stem assembly up or down in the upright post. Retighten the handle.
10. Make any fine adjustments with the angle handle. This is easier to pull bottom arm toward you while turning the handle.
11. Adjust the mouthpiece height by pivoting the t-channel (and arms) from side to side.



Removing the Tuba from the Stand

⚠ CAUTION

Once the stand is accurately adjusted, do not remove the tuba except to put it into its case (for moving to another hall, going on a concert trip, etc).

The instrument should only be removed or reinstalled by two people who know how to place it in the stand accurately and how to adjust the height properly.

Remove the right arm only - not the left or bottom arm.

To save adjustment time when the instrument reinstalled, retain all other adjustments.

Replacement Parts

Item	Description	Item	Description	Item	Description
1	Complete Base Assembly	8	T-Channel Assembly	15	Connector Nut Joint (qty 2)
2	Plastic Cap	9	Height Adjustment Handle	16	Threaded Rod
3	Upright Post Assembly	10	Arm (qty 3)	17	Fiber Washer
4	Handle	11	Bracket Assembly (qty 3)	18	Clamp Nut Assembly
5	Hex Set Screw (qty 2)	12	Knob (qty 6)	19	Jam Nut
6	End Plug (qty 4)	13	Stem Assembly	20	Neoprene Washer
7	Leg Glide (qty 4)	14	Pivot Mount Assembly	21	Fiber Washer

